

REPLACEMENT STEERING CABLES

ORDER GUIDE

Via Milite Ignoto 8A
16012 Busalla (GE) – Italy
T +39 010 9620310/266
F +39 010 9620333
it@ultraflexgroup.it
www.ultraflexgroup.it

HOW TO MEASURE FOR REPLACEMENT STEERING CABLE

D = Conduit length



ORDER LENGTH: "D" dimension + 56 cm

To order in foot length, divide for 30,5 and round up to the next whole foot

Example: $D = 305 \text{ cm} + 56 \text{ cm} = 361 : 30,5 = 11'8''$. Round up to 12 ft